



Installing Left Mulch Baffle on Frontcut & Midcut

After laying out the hardware, remove the deflector chute. Remove template labeled **Left Side Baffle** and fold or cut along dotted lines. From the LH caster mount, measure over (towards center of deck) 7 7/16". From this point, line A on the template will run parallel to the edge of the LH caster mount. Line B will line up with the front edge of the subplate. Mark holes and drill two 11/32" holes into top of deck and bolt LH baffle into place using two 5/16x1 HHCS and two 5/16 Nyloc Nuts. ***** For best results:** drill one hole, bolt in baffle, and use 2nd existing hole in baffle as guide for drilling second hole.

Installing Right Mulch Baffle on Midcut

Remove the two front carriage bolts from the deck lift bracket on the deck. Bolt into the existing holes the RH baffle using two 5/16x1 HHCS and two 5/16 Nyloc Nuts.

Installing Right Mulch Baffle on Frontcut

Remove template labeled **Frontcut 61 Right Side** and fold or cut along dotted lines. From the RH caster mount, measure over (towards center of deck) 7 7/16". From this point, line A on the template will run parallel to edge of the RH caster mount. Line B will line up with the front edge of the subplate. Mark holes and drill two 11/32" holes into top of deck and bolt RH baffle into place using two 5/16x1 HHCS and two 5/16 Nyloc Nuts. ***** For best results:** drill one hole, bolt in baffle, and use 2nd existing hole in baffle as guide for drilling second hole.

At this time, remove existing blades and install three mulch blades included in kit. Torque the blade bolts to 90ft-lbs. Check clearance between blades and baffles. Adjust spindles if necessary. Finally, bolt discharge cover into place using two 5/16x1 HHCS and two 5/16 Nyloc Nuts. Using the discharge cover as a guide, an additional 11/32" hole may be drilled into side of the deck at lower RH corner of discharge cover. Secure into place using 5/16x1 HHCS and 5/16 Nyloc Nut.

Partslist for 61" Prowler

Diagram #	Qty	Part #	Description	Qty	Part#	Description
1	1	592048	Discharge Cover	7	104256	5/16-18 Nyloc Nut
2	3	823354	21" Mulch Blade	7	100273	5/16-18x1 HHCS
3	1	592044	LH Mulch Baffle			
4	1	592046	RH Mulch Baffle			