



# Frontcut Deck

## Installation Instructions

- 1) Move deck to the front of the tractor unit. With footplate raised, slide the drivshaft onto the gearbox after installing the 1/8 x 1" key onto the gearbox shaft. Using the 1/2 x 3/8" setscrews, tighten shaft to 30 ft-lbs.
- 2) Align the deck hanger bars on the tractor with the deck mount plates on the deck. Place the 7/8 x 3-1/2" pins into the holes and install the quick pin.
- 3) Rotate deck lift lever back toward the tractor and install the 3/8 x 2" pin into the deck lift bar in the lowest cutting position (refer to drawing).
- 4) Rotate the deck lift handle into the lowest possible position and install the two 3/8 x 3" pins into the deck hanger brackets.
- 5) Rotate the deck lift handle back toward the tractor and push ball detent pin into slot on deck height adjustment bracket.
- 6) You may then achieve the desired cutting height by changing the pin position in the deck lift bar.

