

## FC Deck Tilt-Up Procedure

### Deck Tilt-Up Procedure

- 1) Fold steering levers into operating position.
- 2) Raise the footplate into vertical position and lock into place.
- 3) Place ring pin into second hole on deck lift bar (hole closest to deck lift handle). At this time pull back the quick-release pin in deck lift handle so that it only engages the lift handle and is no longer running in the adjuster slot. Lower the deck lift handle to the lowest possible position.
- 4) Remove the deck arm ring pins from the deck arms.
- 5) Release the lift handle to relieve the pressure off of the deck lift bar ring pin. Remove the deck lift bar ring pin (this may require weight on the front of the deck).
- 6) Move the deck lift handle to the stow position. Lock into place with the quick-release pin.
- 7) Lift up on the front of the deck until deck rotates past 90 degrees.

### Deck Lowering and Re-attaching

- 1) Rotate the deck back to the horizontal position.
- 2) Release the deck lift handle from the stow position and re-attach the deck lift bar in the forward hole (weight may be required on the front of the deck).
- 3) Move the deck lift handle to the lowest position. Reinstall the deck arm ring pins.
- 4) Move deck lift handle back to allow quick-release pin to be pushed back into adjuster slot.
- 5) Unlatch footplate locking device and lower the footplate back into horizontal position.
- 6) Set the deck to desired height of cut.

