



# Encore Grass Catchers



**Encore Part # 151001**  
Walk-Behind Grass Catcher

**1 Bag / 3 Bushel**



**Encore Part # 151016**  
Z34 Grass Catcher

**1 Bag / 3 Bushel**



**2 Bag / 7 Bushel**

**Encore Part # 151020** (Blower 154017 & Hood 154026)  
**Z42, Z48, Z52** Grass Catcher 2-Bag  
Drive Kits: 152030 (Z42), 152031 (Z48), 152032 (Z52)  
Wght Brkt Kit: 522169 (Z42, Z48, Z52)  
Wght Kit: 821017

**Encore Part # 151028** (Blower 154036 & Hood 154026)  
**Z60, X48, X52** (S/N 53138 & Above), **X60** Grass Catcher 2-Bag  
Drive Kits: 152080 (X48), 152032 (X52), 152082 (Z60\_X60)  
Wght Brkt Kit: 532046 (X48, X52, X60), 522169 (Z60)  
Wght Kit: 821017



**2 Bag / 7 Bushel**

**Encore Part # 151018** (Blower 154025 & Hood 154011)  
**52/61" Prowler Midcut** and **Prowler Frontcut** Grass Catcher 2-Bag  
Drive Kits: 152057 (52 MC), 152058 (61 MC),  
152059 (61 IL3 MC), 152060 (61 IL3 FC),  
152061 (61 FC), 152064 (52 FC)  
Wght Brkt Kit: 592058 (Midcut)  
Wght Kit: 821017



**3 Bag / 10 Bushel**

**Encore Part # 151023** (Blower 154032 & Hood 154030)  
**X52** (Prior to S/N 53138) Grass Catcher 3-Bag  
\*\* Drive Kit components included in Blower Box  
**Encore Part # 151024** (Blower 154033 & Hood 154030)  
**61" Prowler Midcut** Grass Catcher 3-Bag  
\*\* Drive Kit components included in Blower Box  
**Encore Part # 151025** (Blower 154037 & Hood 154030)  
**X60** Grass Catcher 3-Bag  
\*\* Drive Kit components included in Blower Box  
**Encore Part # 151026** (Blower 154035 & Hood 154030)  
**72" Prowler Midcut** Grass Catcher 3-Bag  
\*\* Drive Kit components included in Blower Box

Wght Brkt Kit: 532046 (X-tremes), 592058 (Prowler Midcuts)  
Wght Kit: 821017

When installing 3-Bag Grass Catcher onto Prowler Frontcut, part # 152077 (FC Brkt Kit) must be ordered separately in addition to 151024 or 151026.