



Encore Model Number Chart

How To Read Encore Model Numbers:

<u>Standard Prefix</u>	<u>Deck Size</u>	<u>Engine Model</u>	<u>Horse-Power</u>	<u>Type of Drive</u>	<u>Standard Suffixes</u>
<u>Walk-Behind Units (serial # 46175 and above)</u>					
WB	32	B	12		ES
WB	36	K	13		H
WB	48		17		ESH
<u>Walk-Behind Units (prior to serial # 46175)</u>					
	32	B	1	00	E
	36	K	2	00	
	48		4	50	WT
	52		5	50	EWT
	60				
<u>Z-Rider Units (prior to serial # 43664)</u>					
	34	K	3	50	Z
	42	B	4		
	48		5		
	52		6		
<u>Z-Rider Units (serial # 43664 and above)</u>					
	34	K	15		Z
	42		17		
	48		19		
	52		21		
<u>Prowler Series FC Units</u>					
		C	6		PFC
		K	7		PFC-K
		B	8		
			9		
<u>Prowler Series MC Units (prior to serial # 41004)</u>					
	52	K	6	50	ZP
	61	B	7		
	72		8		P
			9		
<u>Prowler Series MC Units (serial # 41004 and above)</u>					
	52	K	25		A
	61	B	27		L
	72		31		LP
					LD
<u>Horsepower</u>		<u>Standard Suffixes</u>		<u>Standard Prefix</u>	
1 - 12hp Briggs	8 - 27hp Kaw (L/C)	H - Hydro		WB - Walk-Behind	
2 - 14hp Kawasaki	9 - 31hp BS&D-Gas	WT - Wide Track			
3 - 16hp Briggs	12 - 12hp Kawasaki	PFC - Prowler Frontcut		<u>Engine Model</u>	
3 - 15hp Kawasaki	13 - 13hp Kawasaki	E or ES - Electric Start		K - Kawasaki	
4 - 18hp Briggs	15 - 15hp Kawasaki	ESH - Electric Start Hydro		B - Briggs & Stratton	
4 - 17hp Kawasaki	17 - 17hp Kawasaki	Z - Z-Series Rider		C - Kohler	
5 - 20hp Briggs	19 - 19hp Kawasaki	K - Knobby Tires			
5 - 20hp Kaw (L/C)	21 - 21hp Kawasaki	A - Air Cooled		<u>Type of Drive</u>	
5 - 19hp Kawasaki	23 - 23hp Kaw (A/C)	L - Liquid Cooled		00 - Belt Drive	
6 - 22hp Kaw (L/C)	25 - 25hp Kaw (A/C)	ZP - Small Pumps		50 - Hydro Drive	
6 - 21hp Kawasaki	27 - 27hp Kaw (L/C)	LD - Liquid Cooled Diesel			
6 - 22hp Kohler	27 - 27hp BS&D-DSL	LP - Large Pump (BDP 21L)			
7 - 23hp Kaw (A/C)	31 - 31hp BS&D-Gas				
8 - 27hp BS&D-DSL					