



SERVICE BULLETIN

Date: 8/9/2002

Number: SB0206

Subject: BDP-10A Pumps on Encore Prowlers

Details:

When opening the dump valve for transport, you must re-torque the valve to 10 ft/lbs or 80-120 inch/lbs when closing for operation. This will prevent the valve from opening as the pump heats and cools.

Thank you,
Encore Service Department