



# LABOR ALLOWANCE CHART

Warranty Repair Description	Failure Code	Belt-Drive Walk-Behind	Hydro-Drive Walk-Behind	Z34 Rider	Z-Series Rider 42", 48", 52", & 60"	X-treme Riders	Frontcut Prowler	Midcut Prowler
<b>Bearings</b>								
3/4 2-Bolt Bearing	201			0.25	0.25	0.25		
Front Caster Wheel	202	0.25	0.25	0.25	0.25	0.25	0.25	0.25
Drivewheel Bearing	203	0.25						
Blade Spindle Replacement	204	0.50	0.50	0.50	0.50	0.50	0.50	0.50
Blade Spindle Rebuild - Slip Fit	205	0.50	0.50	0.50	0.50	0.50	0.50	0.50
Blade Spindle Rebuild - Press Fit	206	1.00	1.00		1.00			
Driveshaft Replacement	207						0.50	0.50
Driveshaft U-Joint Bearing	208						0.75	0.75
Extension Shaft Bearing	209	0.25						
Neutral Control Shaft Bearing	210				0.25			
Power Shaft Bearing	211						0.50	0.50
<b>Belts</b>								
Blade Drive Belt	212	0.25	0.25	0.50	0.50	0.50	0.50	0.50
Clutch to Powershaft Belt	213						0.25	0.25
Pump Drive Belt	214		0.50	0.75	0.50	0.50	0.50	0.50
RH Blade Belt 48"	215	0.25	0.25					
Transmission Belt	216	0.50						
Wheel Drive Belts	217	0.25						
<b>Bushings</b>								
Caster Support (each)	218	0.25	0.25		0.25	0.25	0.25	
Front Caster Axle Tube	219	0.25	0.25	0.25	0.25	0.25	0.25	0.25
Clutch Belt Tensioner	220						0.50	0.50
Deck Belt Tensioner	221	0.25	0.25	0.25	0.25	0.25	0.25	0.25
Pump Belt Tensioner	222			0.50	0.50	0.50	0.50	0.50
Prowler Caster Arm (pair)	223						0.25	0.25
Prowler Caster Bar (pair)	224						0.25	0.25
Prowler Caster Rod Bushing w/ Zerk	225						0.50	0.50
<b>Brakes</b>								
Brake Band	226	0.50						
Brake Claw (each)	227				0.50		0.50	
Wheel Hub (each)	228		0.50		0.50	0.50	0.50	0.50
Brake Caliper	229							0.50
Brake Pad	230							0.50
Brake Shoes (pair)	231				0.25	0.25	0.25	

Warranty Repair Description	Failure Code	Belt-Drive Walk-Behind	Hydro-Drive Walk-Behind	Z34 Rider	Z-Series Rider 42", 48", 52", & 60"	X-treme Riders	Frontcut Prowler	Midcut Prowler
<b>Decks</b>								
Cutter Deck (32" & 36")	232	2.00	2.00					
Cutter Deck (48")	233	2.50	2.50					
Cutter Deck	234			2.00	3.00	3.00	3.00	3.00
Front Pivot Rollers (pair)	235							0.50
Deck Hanger Chains (each)	236			0.25	0.25	0.25		
Engine Deck	237	1.00	2.00				2.50	2.50
Gearbox Replacement	238						0.50	0.75
Spindle Pulley	239	0.25	0.25	0.25	0.25	0.25	0.25	0.25
Idler Pulley	240	0.25	0.25	0.25	0.25	0.25	0.25	0.25
Tensioner Pulley	241	0.25	0.25	0.25	0.25	0.25	0.25	0.25
Tensioner Arm	242	0.30	0.30	0.30	0.30	0.30	0.30	0.30
Tensioner Spring	243	0.25	0.25	0.25	0.25	0.25	0.25	0.25
Deck Lift Arm	244	0.50	0.50	0.50	0.50	0.50	0.50	0.50
Deck Lift Rod	245				0.25	0.25		
Miscellaneous Welding	246	0.50	0.50	0.50	0.50	0.50	0.50	0.50
<b>Electrical</b>								
Starter Relay / Solenoid	247	0.25	0.25	0.25	0.25	0.25	0.25	0.25
Battery	248	0.25	0.25	0.50	0.50	0.50	0.50	0.50
Battery Cable	249	0.25	0.25	0.25	0.25	0.25	0.25	0.25
Blade Switch	250	0.25	0.25	0.25	0.25	0.25	0.25	0.25
Electric Clutch	251			0.50	0.50	0.50	0.50	0.50
Ignition Switch	252	0.25	0.25	0.25	0.25	0.25	0.25	0.25
Safety Module	253	0.25	0.25	0.25	0.50	0.50	0.50	0.50
Neutral Switch	254	0.25	0.25	0.25	0.25	0.25	0.25	0.25
OPC Switch	255	0.25	0.25					
Park Brake Switch	256			0.25	0.25	0.25	0.25	0.25
Seat Switch	257			0.25	0.25	0.25	0.25	0.25
Hour Meter	258			0.25	0.25	0.25	0.25	0.25
Wire Harness	259	0.50	0.50	0.75	1.50	1.50	1.50	1.50
Diagnostics	260	0.50	0.50	0.50	0.50	0.50	0.50	0.50
<b>Hydraulics</b>								
Hose - Pump to Pump	261		0.25		0.50	0.50	0.50	0.50
Hose - Pump to Wheelmotor	262		0.25		0.50	0.50	0.50	0.50
Hose - Pump to Reservoir	263		0.25		0.50	0.50	0.50	0.50
Reservoir	264		0.50		0.50	0.50	0.50	0.50
Hydro Filter Head	265		0.30		0.30	0.30	0.30	0.30
Hydro Filter	266		0.10		0.10	0.10	0.10	0.10
Hydro Hose Fitting (each)	267		0.25		0.25	0.25	0.25	0.25
Hydraulic Pump Replacement	268		1.50	1.50	1.50	1.50	1.50	1.50
Hydraulic Pump Rebuild / Re-seal	269		0.50	0.50	0.50	0.50	0.50	0.50
Hydraulic Wheelmotor Replacement	270		1.00		1.00	1.00	1.00	1.00

Warranty Repair Description	Failure Code	Belt-Drive Walk-Behind	Hydro-Drive Walk-Behind	Z34 Rider	Z-Series Rider 42", 48", 52", & 60"	X-treme Riders	Frontcut Prowler	Midcut Prowler
<b>Hydraulics cont.</b>								
Hydraulic Wheelmotor Rebuild / Re-seal	271		0.50		0.50	0.50	0.50	0.50
Pump Pulley	272		0.50		0.75	0.75	0.75	0.75
Rod End	273		0.25	0.25	0.25	0.25	0.25	0.25
<b>Miscellaneous</b>								
Fuel Tank	274	0.10	0.10	0.50	0.50	0.50	0.50	0.50
Fuel Line	275	0.10	0.10	0.10	0.10	0.10	0.10	0.10
Fuel Valve & Grommet	276	0.25	0.25	0.25	0.25	0.25	0.25	0.25
Seat Complete	277			0.25	0.25	0.25	0.25	0.25
Seat Pad	278			0.25	0.25	0.25	0.25	0.25
Seat Cable	279			0.10	0.10	0.10	0.10	0.10
Throttle Cable	280	0.25	0.25	0.50	0.50	0.50	0.50	0.50
Choke Cable	281	0.25	0.25	0.50	0.50	0.50	0.50	0.50
Dampening Cylinder	282				0.25	0.25	0.25	0.25
Pump Drive Pulley	283		0.25	0.50	0.50	0.50	0.50	0.50
Blade Belt Drive Pulley	284	0.25	0.25				0.25	0.25
Caster Yoke/Strut	285	0.25	0.25	0.25	0.25	0.25	0.25	0.25
Drive Wheel & Tire Complete	286	0.25	0.10	0.10	0.10	0.10	0.10	0.10
Drive Tire Only	287	0.50	0.50	0.50	0.50	0.50	0.50	0.50
Front Caster Wheel & Tire Complete	288	0.10	0.10	0.10	0.10	0.10	0.10	0.10
Front Caster Tire Only	289	0.50	0.50	0.50	0.50	0.50	0.50	0.50
Handle Assembly	290	0.50	0.50					
Handle - Motion Control	291			0.10	0.10	0.10	0.10	0.10
<b>Grass Catcher</b>								
Backplate	292	0.25	0.25	0.25				
Backplate Support	293	0.25	0.25	0.25				
Grass Bag	294	0.10	0.10	0.10	0.10	0.10	0.10	0.10
Blower Housing Bearing	295				0.25	0.25	0.25	0.25
Blower Housing Liner	296				1.00	1.00	1.00	1.00
Hood Frame	297				0.50	0.50	0.50	0.50
Impeller	298				0.75	0.75	0.75	0.75
Blower Driven Pulley	299				0.25	0.25	0.25	0.25
Blower Drive Belt	300				0.25	0.25	0.25	0.25
Blower Tensioner Pulley	301				0.10	0.10	0.10	0.10
<b>Sulky</b>								
Caster Wheel Bearing (each)	302	0.25						
Caster - Rim Only	303	0.50						
Caster Strut	304	0.25						
Caster - Tire Only	305	0.50						
Caster Wheel Complete	306	0.10						
Steering Rod	307	0.25						
Tie Rod	308	0.25						