


Z34 Jackshaft Assembly



Item #	Qty	Part #	Description
1	1	363380	Spindle Housing
2	2	363350	Spindle Bearing
3	1	583113	Bearing Spacer Tube
4	1	343030	Spindle Shaft
5	1	483078	5.75 Hex Pulley
6	1	343128	Pulley Washer
7	1	363121	Wheel Washer
8	1	343126	5-3/4 Hex Pulley
9	1	104261	5/8-11 Hex Nut
10	2	109025	5/8 Heavy Flat Washer
11	1	100348	5/8-11 x 7 HHCS
12	1	343029	Jackshaft Spindle Assy